



# User manual




**VESTIDE**  
WONEN VOOR STUDENTEN

## 1.1 Create account

In order to use the laundromat you will first need an account. You can create one via <http://laundry.vandeweijer.com>.

Open this website. Then you see the next page:




The screenshot shows the Pay2Wash website interface. At the top left is the logo 'Pay2Wash' and at the top right is the language selector 'EN'. Below the header, the text reads: 'Please choose your location below or enter the location code of the laundromat.' There are two input fields: the first is a dropdown menu labeled 'Select Location' with a downward arrow, and the second is a text box labeled 'Location code \*'. Below the first field, there is a link 'Select location nearest to me...' and the text '- or -'. Below the second field, there is a note: '\* The location code is a unique code that can be found in the laundromat.' At the bottom of the form is a blue button labeled 'Continue'.

- 1) Choose **Aurora TU/e**.
- 2) The location code is: **ZB1465**.







Then click on the button 'Continu'.

- 3) Fill in your email address and choose a password.



The screenshot shows the Pay2Wash website interface. At the top left is the logo 'Pay2Wash' and at the top right is the language selector 'EN'. Below the header, the text reads: 'Welcome to this Pay2Wash location operated by Van De Weijer Laundry B.V.' Below this, the text says 'Please login below'. There are two input fields: the first is labeled 'Email address' and the second is labeled 'Password' with an asterisk. Below the first field, there is a checkbox labeled 'Remember Me'. At the bottom of the form is a blue button labeled 'Log in'. Below the button, there is a link 'Forgot your password?' and the text 'Don't have an account yet? Click below to register. (It's free! :-)' At the bottom of the form is a button labeled 'REGISTER'.

Fill in your details below:

	<input type="text" value="Name"/>
	<input type="text" value="Email address"/>
	<input type="password" value="Password"/>
	<input type="password" value="Confirm password"/>
	<input type="text" value="English"/>
	<input type="text" value="Location code *"/>

\* The location code is a unique code that can be found in the laundromat.

I agree to the [Terms & Conditions](#) and the [Privacy policy](#)

Register

Click on the button 'REGISTER'.

- 4) Fill in your details. Check the box next to *I agree to the Terms & Conditions and the Privacy Policy* after you read it.
- 5) Then click on 'Register' again.

## 1.2 User account

When your account has been created you can login using your username and password. You will then be taken to your personal account page that displays the following options:

The screenshot shows the Day2Wash user account interface. At the top left is the logo 'Day2Wash'. To the right are links for 'Home', 'My account', 'EN #', and a 'Logout' button. Below the navigation bar, the 'Location' is set to 'Lombokpad (Show on map)'. A blue box highlights the 'Account balance:' field, which shows '€0,00' with a plus sign. A red minus sign is next to the balance. A legend indicates that red text means 'unavailable' and green text means 'in use by you'. Under 'Tumble dryers', three units (D1, D2, D3) are shown, all with red text. Under 'Washing machines', five units (W1, W2, W3, W4, W5) are shown, all with green text. A legend at the bottom left explains the color coding: red = unavailable, green = in use by you. Numbered annotations are present: '1' points to the account balance, '2' points to the plus sign, '3' points to the appliance grid, and '4' points to the Logout button.

Day2Wash

Home My account EN # Logout

Location: Lombokpad (Show on map)

Account balance: €0,00 +

Select one of the available appliances below.

**Tumble dryers:**

D1 D2 D3


**Washing machines:**

W1 W2 W3 W4 W5

red = unavailable  
green = in use by you

1. Your credits
2. Add credits
3. Current availability
4. Log out

### 1.3 Add Credits

You will be able to add money to your account. You can do so by clicking on €0,00  .

- 1) Click or fill in the amount that you would like to add.
- 2) Select the payment method. You can pay using: iDEAL, Bank transfer, PayPal or credit card.
- 3) Click on 'Complete transaction'.

Account balance: €0,00

---

Select the desired amount to add:

*Amounts below 20.00 are subject to an extra transaction fee.*

---

Payment method fee:

Transaction fee:


---

**Total amount due:**

- 4) After you made the transaction you need to log in again. Now you see that the balance is upgraded to the amount you chose.

## 1.4 Transaction history

Go to 'My account'. Click on 'View transactions' to see the history of your transactions.



## 1.5 The Laundromat


Display with user options;

1) Language etc.

2) You can choose your options by choosing the number, which you can find before the menu item using the keypad

3) Hold card for NFC payment

4) Not in use



## 1.6 Selecting an appliance by using the laundromat terminal



The terminal will show you which appliance is available for use. (If one is crossed out it means it's not available.)

- 1) You can select an available appliance by punching in its number on the keypad.
- 2) Confirm your selection by pressing the green “V” symbol.
- 3) If you have enough money in your account, the chosen appliance will be activated for operation. (You can cancel by using the red “↶” button on the left side.) You will have to start the washer or dryer at the appliance itself. If you wait for too long, the activation will expire.



### **Attention:**

- THE AMOUNT YOU HAVE TO PAY MUST BE ALWAYS AVAILABLE ON YOUR ACCOUNT.
- YOU HAVE TO START THE WASHING MACHINE OR THE DRYER YOURSELF ON THE MACHINE ITSELF.
- IF YOU WAIT TO LONG TO START MACHINE THE ACTIVATION CAN EXPIRE.

## 1.7 Adding money to your account using the laundromat terminal

- 1) Go to “Upgrade credits” on the main screen by selecting the corresponding number on the keypad.
- 2) Present your QR-code when asked. Next you can enter the amount that you would like to add (€ 1,- minimum) and you confirm this by pressing the green “V” button.
- 3) After that you will have to present your bank card to the contactless payment terminal.

**Please note:** Your card has to be compatible with the contactless payment standard. In general you can recognize a compatible card if this logo is printed on it:



If your card is not compatible, you can add money to your account by using your personal account page. (See description above.)